CABINET PARTS

REFRIGERATOR

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04

(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2314273	Service & Wiring Sheet
	2302183	Energy Label
	2314472	Use & Care Guide
Following May Be Purchased		
DO−IT−YOURSELF REPAIR MANUALS		
	677969	Do−It−Yourself Manual, Ref./Fzr.
2	2189410	Hinge (Top)
3	2166108	Roller, Front (2)
4	489427	Screw
5	489341	Washer
6	2179826	Rivet
7	3400504	Screw
9	489497	Screw
10	2183972	Hinge, Center
11	2183854	Shim, Hinge Center
13	2189194	Hinge Butt
14		Fitting, Water Tube (Not Serviced)
15		Hole Plug (6)
	2201012	White
	2200924	Biscuit
	2183998	Black
16		Seal, Front (Not Serviced)
17		Seal, Rear (Not Serviced)
18		Corner Filler (2)
	2201014	White
	2200926	Biscuit
	2201017	Black
19		Grille (Includes Illus. 20)
	2254313	White
	2254316	Biscuit
	2254315	Black
20	2189356	Clip, Grille (2)
21	487576	Washer
22		Cover, Hinge
	2213360	White
	2213364	Biscuit
	2213363	Black
23		Rail, Center (Not Serviced)
24	2202884	Cover, Unit
25		Cabinet (Not a Serviceable Part)
26	2172743	Spacer, Hinge Bottom

DOOR PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04

(White) (Biscuit) (Black)



DOOR PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04

(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Illus. 2,3,9 & 17)
	2183920	White
	2205284	Biscuit
	2200714	Black
2	939101	Screw Anchor
3	2183198	Tap Plate
5		Handle, Refrigerator
	2202807W	White
	2202807T	Biscuit
	2202807B	Black
6	489357	Screw
8	8281146	Screw
9		Door Gasket, Magnetic
	2202875	Mist Beige
	2202882	Black
10		Cover, Screw
	2202819W	White
	2202819T	Biscuit
	2202819B	Black
11	2262218	Nameplate
12	2195378	Trim, Door Shelf
13	8281206	Screw
14		Freezer Door (Includes Illus. 3,17 & 18)
	2182489	White
	2204686	Biscuit
	2200711	Black
15		Hole Plug, Handle
	2189000	White
	2200936	Biscuit
	2189009	Black
16	2188236	Shelf, Flip−Up
17	2183003	Thimble
18		Door Gasket, Magnetic
	2214967	Mist Beige
	2214969	Black
19	2204812	Bin, Door Shelf
20	2189202	Bracket, Door Stop
21	488921	Screw
22		Hole Plug
	2212648	White
	2212649	Biscuit
	2212651	Black
23	2156007	Plug, Trim
24	2156006	Plug, Trim
25	2218118	Compartment Door
26		Handle, Freezer
	2202806W	White
	2202806T	Biscuit
	2202806B	Black
27	2195947	Trim, Door (2)
28	2195916	Endcap, Trim (4)
29	2195948	Trim, Door

LINER PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04

(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not a Serviceable Part)
2	2197380	Grommet (2)
3	2254360	Gasket, Evaporator Cover (2)
4	2314156	Defrost Timer
5	2204640	Thermostat, Tube Barrier
6	941839	Hole Plug
7	2310078	Wire Assembly Control Box
8	2162085	Socket, Light
9	98129	Screw (2)
10	2214986	Fan Motor
11	2163777	Fan Blade
12	2218381	Control Box
13	2225460	Thermostat
14	489478	Screw
15	488208	Screw
16	2254263	Cover, Evaporator
17	2160708	Light Bulb
18	2254454	Bracket Evap. Fan, Rear
19	1118894	Switch, Rocker Arm
21	2176281	Cover, Air Diffuser
22	2202885	Knob, Thermostat
23	2254354	Air Tower
24	2189452	Air Diffuser, Bottom
26	2212439	Air Separator Assembly
27	2205003	Cover, Hole
28	2210509	Valve−Tube, Body
29	2254453	Bracket, Fan Motor
31	2204639	Shield, Heat
32	487996	Cap
33	2310043	Wire Assembly Freezer Compartment (Includes Item 34)
34	2314158	Defrost, BI−Metal

UNIT PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04

(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2225596	Plate, Unit Mounting
3	2214960	Condenser
4	2314157	Heater, Defrost
5	2254249	Evaporator Assy.
6	8533859	Screw
7	2254295	Drain Pan
9	2176301	Bracket, Heater
10	2300638	Extension, Air Baffle
12	4387731	Cover (Service Only)
	2162358	Production
13	4387938	Overload (Service Only)
	2302290	Production
14		Grommet (4)
	1100826	Production
	4387558	Service
15	2258450	Relay
17	2150304	Roller (2)
18	2221797	Rivet
19	2182338	Clip, Heater
20	489373	Screw

Illus. No.	Part No.	DESCRIPTION
21	2169104	Insulation, Sound Dampening
23	2201185	Support Block
24	3400518	Screw
28	2225647	Compressor (Includes Items 12,13,14,29
29		Drier
	2319825	Production
	4387019	Service
30	2155774	Clamp
33	2302249	Air Baffle
34	2188874	Motor, Condenser
35	2187764	Wire Assy, Unit
36	2225834	Fan Blade
37	2205294	Tube, Discharge
38	2205293	Tube, Suction
39	2212848	Tube, Process
40	488500	Screw
41	2300635	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE

4.00 Ozs.
(R134A)

SHELF PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2300520	Shelf, Ladder Center
3	2200988	Glass, Full Shelf
4	2163762	Cup, Shelf Mtg.
5	489478	Screw
6	2188687	Trim Shelf, Rear
7	2201102E	Shelf, Cantilever
8	2188685	Trim, Shelf Front
9	2210526	Crisper Cover
10	2188691	Trim Shelf, Front
11	2210573	Insert, Crisper Cover
12	2201106	Pan Shelf, Cantilever
14	2200987	Glass, Shelf
15	2314478	Crisper Support
16	2201104E	Shelf, Full Cantilever
17	2189454	Shelf, Freezer
18	2188689	Trim, Shelf Rear
19	2188711	Trim Shelf, Side
20	2218132K	Pan, Meat
24	2218130	Crisper Pan (Includes Illus. 25 & 26)
25	2212446	Body, Humidity Control
26	2176222	Slide, Humidity Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET1MHKXMQ04, ET1MHKXMT04, ET1MHKXMB04
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4" x 108")
	876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
	876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	799832	Kit, Porcelain Repair (White)
	503695	Cork Sealer (1/4 Pound)

Customer Touch−Up Material

	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72032	Brush Touch−Up Kit (Black)
	4392899	Brush Touch−Up Kit (Biscuit)

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1 Qt. Uncut)
	833938	Kit, Terminal Connector

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

ICE MAKER FIELD INSTALLABLE

	2155469	ECKMF94

TORX SCREW WRENCH

	1117510	Torx Key